

## Technical Documentation

### MDR-137-P

Pressure control module with integrated power amplifier



**CONTENTS**

1	General Information.....	4
1.1	Order number .....	4
1.2	Scope of supply .....	4
1.3	Accessories .....	4
1.4	Symbols used .....	5
1.5	Legal notice .....	5
1.6	Safety instructions .....	6
2	Characteristics.....	7
2.1	Compatibility.....	8
2.2	Device description .....	9
3	Use and application .....	10
3.1	Installation instructions .....	10
3.2	Typical system structure.....	11
3.3	Method of operation.....	11
3.4	Commissioning .....	12
4	Technical description.....	13
4.1	Input and output signals .....	13
4.2	LED definitions .....	13
4.3	Circuit diagram .....	14
4.4	Typical wiring.....	15
4.5	Connection examples .....	15
4.6	Technical data .....	16
5	Parameters.....	17
5.1	Parameter overview.....	17
5.2	Basic parameters.....	19
5.2.1	LG (Changing the language).....	19
5.2.2	MODE (Parameter view).....	19
5.2.3	SENS (Malfunction monitor) .....	19
5.2.4	EOUT (Output signal if not ready).....	20
5.3	InSignal adaptation.....	20
5.3.1	SYS_RANGE (System pressure).....	20
5.3.2	SIGNAL (Type of input signal) .....	20
5.3.3	N_RANGE:X (Sensor nominal pressure).....	21
5.3.4	OFFSET:X (Sensor offset).....	21
5.3.5	Using of the commands SYS_RANGE, N_RANGE:X and OFFSET:X .....	21
5.3.6	RA (Command signal ramp time).....	22
5.4	Control parameters.....	23
5.4.1	PID controller .....	23
5.4.2	Integrator control function .....	24
5.5	Output signal adaptation.....	25
5.5.1	MIN (Deadband compensation) .....	25
5.5.2	MAX (Output scaling).....	25
5.5.3	TRIGGER (Response threshold for the MIN parameter) .....	25
5.5.4	SIGNAL:U (Output polarity) .....	26
5.6	Output signal adaptation.....	26
5.6.1	CURRENT (Rated solenoid current).....	26
5.6.2	DFREQ (Dither frequency).....	26
5.6.3	DAMPL (Dither amplitude) .....	26
5.6.4	PWM (PWM Frequency) .....	27
5.6.5	ACC (Current loop auto adjustment).....	27

5.6.6	PPWM (P gain of the current loop) .....	27
5.6.7	IPWM (I gain of the current loop) .....	27
5.7	Special commands .....	28
5.7.1	TS (Sample time) .....	28
5.7.2	AINMODE (Scaling mode) .....	28
5.7.3	AIN (Analogue input scaling).....	29
5.8	PROCESS DATA (Monitoring).....	30
6	Appendix.....	31
6.1	Failure monitoring .....	31
6.2	Troubleshooting .....	31
6.3	Description of the command structure .....	34
7	Notes .....	35

## 1 General Information

### 1.1 Order number

**MDR-137-P-2030**<sup>1</sup> - pressure control module with integrated power output stage up to 2,6 A and analogue interface

#### Alternative products

**MDR-133-U**<sup>2</sup> - with programmable output ( $\pm 10$  V differential output or 4... 20 mA) and a higher signal release (for test plant and applications with a signal release < 0,001 %)

**MDR-133-P** - with integrated power stage and higher signal release (for test plant and applications with a signal release < 0,001 %)

### 1.2 Scope of supply

The scope of supply includes the module plus the terminal blocks which are part of the housing.

The Profibus plug, interface cables and further parts which may be required should be ordered separately.

This documentation can be downloaded as a PDF file from [www.w-e-st.de](http://www.w-e-st.de).

### 1.3 Accessories

**WPC-300** - Start-Up-Tool (downloadable from our homepage – products/software)

---

<sup>1</sup> The number of the version consists of the hardware version (first two digits) and the software version (last two digits). Because of the development of the products these numbers can vary. They are not strictly necessary for the order. We will always deliver the newest version.

<sup>2</sup> Compared with older versions (ordering code **A** for voltages output and **I** for current output) the code **U** (universal) is used for programmable outputs.

## 1.4 Symbols used



General information



Safety-related information

## 1.5 Legal notice

**W.E.St.** Elektronik GmbH

Gewerbering 31  
D-41372 Niederkrüchten

Tel.: +49 (0)2163 577355-0  
Fax.: +49 (0)2163 577355-11

Home page: [www.w-e-st.de](http://www.w-e-st.de) or [www.west-electronics.com](http://www.west-electronics.com)  
EMAIL: [info@w-e-st.de](mailto:info@w-e-st.de)

Date: 30.12.2015

The data and characteristics described herein serve only to describe the product. The user is required to evaluate this data and to check suitability for the particular application. General suitability cannot be inferred from this document. We reserve the right to make technical modifications due to further development of the product described in this manual. The technical information and dimensions are non-binding. No claims may be made based on them.

This document is copyright.

## 1.6 Safety instructions

Please read this document and the safety instructions carefully. This document will help to define the product area of application and to put it into operation. Additional documents (WPC-300 for the start-up software) and knowledge of the application should be taken into account or be available.

General regulations and laws (depending on the country: e. g. accident prevention and environmental protection) must be complied with.



These modules are designed for hydraulic applications in open or closed-loop control circuits. Uncontrolled movements can be caused by device defects (in the hydraulic module or the components), application errors and electrical faults. Work on the drive or the electronics must only be carried out whilst the equipment is switched off and not under pressure.



This handbook describes the functions and the electrical connections for this electronic assembly. All technical documents which pertain to the system must be complied with when commissioning.



This device may only be connected and put into operation by trained specialist staff. The instruction manual must be read with care. The installation instructions and the commissioning instructions must be followed. Guarantee and liability claims are invalid if the instructions are not complied with and/or in case of incorrect installation or inappropriate use.



### **CAUTION!**

All electronic modules are manufactured to a high quality. Malfunctions due to the failure of components cannot, however, be excluded. Despite extensive testing the same also applies for the software. If these devices are deployed in safety-relevant applications, suitable external measures must be taken to guarantee the necessary safety. The same applies for faults which affect safety. No liability can be assumed for possible damage.



### **Further instructions**

- The module may only be operated in compliance with the national EMC regulations. It is the user's responsibility to adhere to these regulations.
- The device is only intended for use in the commercial sector.
- When not in use the module must be protected from the effects of the weather, contamination and mechanical damage.
- The module may not be used in an explosive environment.
- To ensure adequate cooling the ventilation slots must not be covered.
- The device must be disposed of in accordance with national statutory provisions.

## 2 Characteristics

This module has been developed for controlling pressure and force (and optionally speed, too) in hydraulic systems. The controller structure is optimized for pressure closed-loop control systems with typical pressure valves (pressure reducing or pressure relieve valves and also for pressure controlled servo pumps). An integrated power stage and high dynamic control loops (1 ms for pressure control and 0.125 ms for the current loop control) offer a simple and powerful solution.

The control loop is designed as bypass control function, where the input signal is linked via a control parameter directly to the control output (pressure valve) and the PID compensator has to control the linearity deviation only. In many cases the optimization can be carried out without further test equipment (only a pressure sensor is needed).

The output signal is available as an integrated PWM power signal in steps of 1.0, 1.6 and 2.6 A. This output is over-current and short-circuit protected.

Because of the easy handling a very short training period is guaranteed.

**Typical applications:** General pressure control with pressure valves (direct or via a servo pump).

## Features

- **Activation of pressure reducing valve and pressure control valve**
- **Compact housing**
- **Digital reproducible adjustments**
- **Universal PID actuator**
- **Free parameterization of ramps, MIN and MAX, DITHER (frequency, amplitude) and PWM frequency**
- **Current range (via software switchable) up to 2,6 A**
- **Application orientated parameter settings**
- **Fault diagnosis and extended function checking**
- **Simplified parameterization with WPC-300 software**

## 2.1 Compatibility

As a result of further developments some smaller changes have to be taken in consideration.

### Functionality:


1. Downward compatible to the older module
2. 100 % wiring compatible
3. **Baud rate:** The default baud rate has changed from 9600 baud to 57600 baud. This is adaptable in WPC-300: OPTIONS/SETTINGS/INTERFACE.  
FIXBAUDRATE = 57600 and/or AUTO BAUDRATE DETECTION = 57600

### Parameterization:


1. Standardizing of parameter names
2. Simplified and intuitive parameterization of the analogue inputs and sensors
3. Compatibility mode of the input scaling (**AINMODE**), if necessary
4. Adaptation of the polarity of the output signal with the command **SIGNAL:U** (the **POL** commando is removed)



## 2.2 Device description



Typenschild und Anschlussbelegung  
Type plate and terminal pin assignment



## 3 Use and application


### 3.1 Installation instructions

- This module is designed for installation in a shielded EMC housing (control cabinet). All cables which lead outside must be screened; complete screening is required. It is also necessary to avoid strong electro-magnetic interference sources being installed nearby when using our open and closed loop control modules.
- **Typical installation location:** 24 V control signal area (close to PLC)  
The devices must be arranged in the control cabinet so that the power section and the signal section are separate from each other.  
Experience shows that the installation place close to the PLC (24 V area) is most suitable. All digital and analogue inputs and outputs are fitted with filters and surge absorbers in the device.
- The module should be installed and wired in accordance with the documentation bearing in mind EMC principles. If other consumers are operated with the same power supply, a star-shaped ground wiring scheme is recommended. The following points must be observed when wiring:
  - The signal cables must be laid separately from power cables.
  - Analogue signal cables **must be screened**.
  - All other cables must be screened if there are powerful interference sources (frequency converters, power contactors) and cable lengths > 3 m. Inexpensive SMD ferrites can be used with high-frequency radiation.
  - The screening should be connected to PE (PE terminal) as close to the module as possible. The local requirements for screening must be taken into account in all cases. The screening should be connected to at both ends. Equipotential bonding must be provided where there are differences between the connected electrical components.
  - If having longer lengths of cable (> 10 m), the diameters and screening measures should be checked by specialists (e. g. for possible interference, noise sources and voltage drop). Special care is required if using cables of over 40 m in length, and if necessary the manufacturer should be consulted if necessary.
- A low-resistance connection between PE and the mounting rail should be provided. Transient interference is transmitted from the module directly to the mounting rail and from there to the local earth.
- Power should be supplied by a regulated power supply unit (typically a PELV system complying with IEC364-4-4, secure low voltage). The low internal resistance of regulated power supplies gives better interference voltage dissipation, which improves the signal quality of high-resolution sensors in particular. Switched inductances (relays and valve coils) which are connected to the same power supply must always be provided with appropriate overvoltage protection directly at the coil.

### 3.2 Typical system structure

This minimal system consists of the following components:

- (\*1) Pressure relieve valve (alternative: pressure controlled servo pump)
- (\*2) Cylinder / actuator
- (\*3) MDR-137-P pressure control module with integrated power amplifier
- (\*4) Interface to PLC with analogue and digital signals
- (\*5) Pressure or force sensor (0... 10 V or 4... 20 mA)



### 3.3 Method of operation

This module is useful for pressure control in very different applications. The output signal (up to 2.6 A) controls various pressure valves (pressure relieve valves and pressure control valves). No OBE electronic is necessary.

Because of the very high stability of the pressure control structure this module is recommended where open loop applications are not sufficient concerning the accuracy.

Pressure controls with constant pumps or remote controllable servo pumps and for force and torque controls with cylinders and motor drives are typical applications.

The controlling is realized by a PID controller optimized for this application.

**ENABLE:** This digital input signal initializes the application. Error messages are deleted. The power stage gets active and the **READY** signal indicates that all components are working correctly. Now the controller can be driven by the command value as simple power amplifier. With the **START** signal the PID controller gets activated. The feedback input will be evaluated and the output will be generated according to the control deviation and the parameterization.

### 3.4 Commissioning

Step	Task
Installation	Install the device in accordance with the circuit diagram. Ensure it is wired correctly and that the signals are well shielded. The device must be installed in a protective housing (control cabinet or similar).
Switching on for the first time	Ensure that no unwanted movement is possible in the drive (e. g. switch off the hydraulics). Connect an ammeter and check the current consumed by the device. If it is higher than specified, there is an error in the wiring. Switch the device off immediately and check the wiring.
Setting up communication	Once the power input is correct the PC (notebook) should be connected to the serial interface. Please see the WPC-300 program documentation for how to set up communication. Further commissioning and diagnosis are supported by the operating software.
Pre-parameterization	Parameterize now (with the help of the system redundancy and the connection diagram) the following parameters: The NOMINAL SYSTEM PRESSURE and the ANALOGUE INPUTS. See specifications of the system and the sensors. The output CURRENT and the typical valve parameter DITHER and MIN/MAX. Pre-parameterization is necessary to minimize the risk of an unintentional movement / pressure.
Control signal	Check the control signal (output signal). The control signal (PIN 3 and PIN 4) lies in the range of 0... 2,6 A. In the current state it should show around 0 A. <b>CAUTION!</b> This signal depends on the EOUI setting.
Switching on the hydraulics	The hydraulics can now be switched on. The module is not yet generating a signal. Drives should be at a standstill or drift slightly (leave its position at a slow speed).
Activating ENABLE	<b>CAUTION!</b> The power stage gets activated. With active ENABLE the module works as a simple power amplifier. The output current to the valve (and also the pressure) will follow the input signal proportionally.
Activating START	Activation of the START input will activate the closed loop controller. With the correct pre-adjustment the system works in closed loop mode. The behavior of the pressure loop can be controlled with WPC-300 (MONITOR).
Controller optimization	The DEFAULT adjustment of the module (C and LIM parameter) is working in a satisfied manner in many cases. To improve the pressure loop the different PID parameters have to be adjusted depending on the application.

## 4 Technical description


### 4.1 Input and output signals

Connection	Supply
PIN 7	Power supply (see technical data)
PIN 8	0 V (GND) connection.
Connection	Analogue signals
PIN 9 / 10	Pressure command value (WA), signal range 0... 10 V or 4... 20 mA, scalable (SIGNAL W)
PIN 13 /14	Pressure feedback value (X), signal range 0... 10 V or 4... 20 mA, scalable (SIGNAL X)
PIN 11	0 V (GND) connection for analogue signals
PIN 12	8V reference voltage output
PIN 3 / 4	PWM output to the solenoid
Connection	Digital inputs and outputs
PIN 15	<b>Enable input:</b> Generally enabling of the application.
PIN 6	<b>RUN (Start) Input:</b> <b>ON:</b> The controller is active. <b>OFF:</b> The controller is not active.
PIN 5	<b>READY output:</b> <b>ON:</b> The module is enabled; there are no discernable errors. <b>OFF:</b> ENABLE (PIN 15) is not active or an error has been detected.


### 4.2 LED definitions

LEDs	Description of the LED function
GREEN	Identical to the READY output. <b>OFF:</b> No power supply or ENABLE is not activated <b>ON:</b> System is ready for peration  <b>Flashing:</b> Error discovered Only active when SENS = ON
YELLOW A	Intensity of the solenoid current
GREEN + YELLOW A	1. <b>Chasing light (over all LEDs):</b> The bootloader is active. No normal functions are possible. 2. <b>All LEDs flash shortly every 6 s:</b> An internal data error was detected and corrected automatically! The module still works regularly. To acknowledge the error the module has to be cycle powered.
YELLOW A + YELLOW B	<b>Both yellow LEDs flash oppositely every 1 s:</b> The nonvolatile stored parameters are inconsistent! To acknowledge the error, data has to be saved with the SAVE command or the corresponding button in the WPC.

### 4.3 Circuit diagram




## 4.4 Typical wiring




## 4.5 Connection examples


Joystick




4... 20 mA input



SPS / PLC 0... 10 V / +/- 10 V



Potentiometer / Joystick



## 4.6 Technical data

Supply voltage (U <sub>b</sub> )	[VDC]	12... 30 (incl. ripple)
Current requirement	[mA]	60 + solenoid current
External protection	[A]	3 medium time lag
Reference voltage	[V]	8 (max. 25 mA load)
Digital inputs	[V]	OFF : < 2
	[V]	ON : > 10
Input resistance	[kOhm]	25
Digital outputs	[V]	OFF: < 2
	[V]	ON: max. U <sub>b</sub>
Maximum current	[mA]	50
Analogue inputs:	[V]	0... 10; min. 90 kOhm
	[mA]	4... 20; 390 Ohm
Signal resolution	[%]	0,006 incl. Oversampling
PWM output	[A]	0,5, to 2,6 (step less selectable); broken wire and short circuit monitored
PWM frequency	[Hz]	61... 2604
Sample time (pressure control)	[ms]	1
Sample time (solenoid current control)	[ms]	0,125
Serial interface		USB type B Virtual COM port driver (WPC-300): 9600... 57600 Baud (Default = 57600), 1 Stopbit, No parity, No handshake
Housing		Snap-on module to EN 50022 PA 6.6 polyamide Flammability class V0 (UL94)
Weight	[kg]	0,190
Protection class		IP20
Temperature range	[°C]	-20... 60
Storage temperature	[°C]	-20... 70
Humidity	[%]	< 95 (non-condensing)
Connections		USB Typ B 4 x 4-pole terminal blocks PE: via the DIN mounting rail
EMC		EN 61000-6-2: 8/2005 EN 61000-6-4: 6/2007 + A1:2011



## 5 Parameters

### 5.1 Parameter overview

Group	Command	Default	Unit	Description
Basic parameters				
	LG	EN	-	Changing language help texts
	MODE	STD	-	Parameter view
	SENS	ON	-	Malfunction monitor
	EOUT	0	0,01 %	Output signal if not ready
Input signal adaptation				
	SYS_RANGE	100	bar	System pressure
Sensor scaling				
	SIGNAL:X	U0-10	V	Type of input
	N_RANGE:X	100	bar	Sensor nominal pressure
	OFFSET:X	0	mbar	Sensor offset
Command signal scaling				
	SIGNAL:W	U0-10	mbar	Type of input
Ramp function				
	RA:UP	100	ms	Command signal ramp times
	RA:DOWN	100	ms	
Control parameters				
PID controller				
	C:P	50	0,01	P gain
	C:I	4000	0,1 ms	I gain
	C:D	0	0,1 ms	D gain
	C:D_T1	500	0,1 ms	D gain filter
	C:FF	8000	0,01 %	Feed forward
Integrator control				
	C:I_LIM	2500	0,01 %	Integrator limitation
	C:I_ACT	2500	0,01 %	Integrator activation threshold
Output signal adaptation				
	MIN	0	0,01 %	Deadband compensation
	MAX	10000	0,01 %	Output scaling
	TRIGGER	200	0,01 %	Deadband compensation trigger point
	SIGNAL:U	+	-	Output polarity
Powerstage parameters				
	CURRENT	1000	mA	Rated solenoid current
	DFREQ	121	Hz	Dither frequency
	DAMPL	500	0,01 %	Dither amplitude
	PWM	2604	Hz	PWM frequency
	ACC	ON	-	Current loop auto adjustment
	PPWM	7	-	Gain of the current loop
	IPWM	40	-	

Group	Command	Default	Unit	Description
<b>Special commands</b>				
<i>Sample time</i>				
	<b>TS</b>	10	0,1 ms	Sample time of the control loop
<i>Scaling mode</i>				
	<b>AINMODE</b>	EASY	-	Input scaling mode
	<b>AIN:X</b>	A: 1000	-	Free scaling of the analogue inputs. Gets activated when AINMODE is switched over to MATH.
	<b>AIN:W</b>	B: 1000	-	
		C: 0	0,01 %	
		X: V	-	

## 5.2 Basic parameters

### 5.2.1 LG (Changing the language)

Command	Parameters	Unit	Group
LG x	x= DE   EN	–	STD

Either German or English can be selected for the help texts.



**CAUTION:** After changing the language settings, the ID button in the menu bar (WPC-300) must be pressed (module identification).

### 5.2.2 MODE (Parameter view)

Command	Parameters	Unit	Group
MODE x	x= STD   EXP	–	STD

This command changes the operating mode. Various commands (defined via STD/EXP) are blanked out in Standard Mode. The commands in Expert Mode have a more significant influence on system behavior and should accordingly be changed with care.

### 5.2.3 SENS (Malfunction monitor)

Command	Parameters	Unit	Group
SENS x	x= ON   OFF   AUTO	–	STD

This command is used to activate/deactivate the monitoring functions (4... 20 mA sensors, output current, signal range and internal failures) of the module.

ON: All monitoring functions are active. Detected failures can be reset by deactivating the ENABLE input.

OFF: No monitoring function is active.

AUTO: Auto reset mode. All monitoring functions are active. If the failure doesn't exist anymore, the module automatically resumes to work.



Normally the monitoring functions are always active because otherwise no errors are detectable via the READY output. Deactivating is possible mainly for troubleshooting.

### 5.2.4 EOUT (Output signal if not ready)

Command	Parameters	Unit	Group
EOUT X	x= -10000... 10000	0,01 %	EXP

Output value in case of a detected error or a deactive ENABLE input. A value (degree of valve opening) for use in the event of a sensor error (or the module is disabled) can be defined here. This function can be used if, for example, the drive is to move to one of the two end positions (at the specified speed) in case of a sensor error.

|EOUT| = 0 The output is switched off in the event of an error. This is normal behavior.



#### CAUTION!

The output value defined here is stored permanently (independently of the parameter set). The effects should be analyzed by the user for each application from the point of view of safety.

## 5.3 InSignal adaptation

### 5.3.1 SYS\_RANGE (System pressure)

Command	Parameters	Unit	Group
SYS_RANGE X	x= 10... 1000	bar	STD

This command defines the pressure, which corresponds to 100 % of the input signal. If the demand is set incorrectly, this leads to incorrect system settings, and the dependent parameters cannot be calculated correctly.

### 5.3.2 SIGNAL (Type of input signal)

Command	Parameters	Unit	Group
SIGNAL:I X	i= W X x= OFF U0-10 I4-20	–	EASY

This command can be used to change the type of input signal (voltages or current) and to define the direction of the signal. This command is available for all analogue inputs (W and X).  
OFF= Deactivation of the input

### 5.3.3 N\_RANGE:X (Sensor nominal pressure)

Command	Parameter	Unit	Group
N_RANGE:X X	x= 10... 10000	bar	EASY

N\_RANGE (nominal range) is used to define the length of the sensor. This value should be always higher than SYS\_RANGE. The control parameter cannot be calculated correctly in case of wrong values.

### 5.3.4 OFFSET:X (Sensor offset)

Command	Parameter	Unit	Group
OFFSET:X X	x= -60000... 60000	mbar	EASY

Adjustment of the zero point of the sensor.

### 5.3.5 Using of the commands SYS\_RANGE, N\_RANGE:X and OFFSET:X

With these commands, the feedback sensor is scaled. Suppose you have a pressure control with the following characteristics:

- The system pressure is 350 bar
- The pressure sensor has a 4-20mA current output
- The nominal pressure of the sensor is 600bar (20mA at 600bar)
- The sensor has an offset of 3bar (at 0bar real pressure 3bar are displayed)

To scale this sensor correctly the following settings should be made:


- SYS\_RANGE 350 bar
- SIGNAL:X I4-20
- N\_RANGE:X 600 bar
- OFFSET:X -3000 mbar

### 5.3.6 RA (Command signal ramp time)

Command	Parameter	Unit	Group
RA:I      X	i= UP   DOWN x= 1... 600000	ms	STD

Two quadrant ramp function.

The ramp time is separately set for UP and DOWN ramps.



## 5.4 Control parameters

### 5.4.1 PID controller


Command	Parameter	Unit	Group
C:I X	I= P I D D_T1 FF :P x= 0... 10000 :I x= 0... 30000 :D x= 0... 1200 :D_T1 x= 0... 1000 :FF x= 0... 10000	0,01 0,1 ms 0,1 ms 0,1 ms 0,01 %	STD

The control function will be parameterized via this command.

The P, I and D gain are similar to a standard PID controller. The T1 factor is used for the D-gain in order to suppress high-frequency noise.

The FF value is a forward control value to control the output by the input signal directly. The PID closed loop control function has only to adjust the difference (the error).

Value 0 deactivates the integrator.



### 5.4.2 Integrator control function

Command	Parameter	Unit	Group
C:I_LIM X	x= 0... 10000	0,01 %	STD
C:I_ACT X	x= 0... 10000	0,01 %	

The integrator function is controlled by this command.

**C:I\_LIM** Limitation of the integrator range (faster control function by reduced pressure overshoots). By a high nonlinearity of the valve the LIM value must be sufficient to compensate it.

**C:I\_ACT** Controls the integrator function. To reduce pressure overshoots, an activation point for the integrator can be programmed via the (I\_ACT) value. The integrator is activated if the actual pressure is higher than the programmed threshold:



## 5.5 Output signal adaptation

### 5.5.1 MIN (Deadband compensation)

### 5.5.2 MAX (Output scaling)


### 5.5.3 TRIGGER (Response threshold for the MIN parameter)

Command		Parameters	Unit	Group
MIN:I	X	x= 0... 6000	0,01 %	STD
MAX:I	X	x= 3000... 10000	0,01 %	
TRIGGER	X	x= 0... 3000	0,01 %	

With this command, the output signal is adjusted to the valve characteristics. With the MAX value the output signal (the maximum valve current) will be defined. With the MIN value the overlap (dead band of the valve) will be compensated. Via the TRIGGER the activation point of the MIN function is set and so a non-sensitive range around the zero-point<sup>3</sup> can be specified.



**CAUTION:** If the MIN value is set too high, it influences the minimal pressure, which cannot be adjusted any longer. In extreme case this causes to an oscillating at small input values.



<sup>3</sup> This dead band is necessary, in order to avoid unrequested activations caused by small variations of the input signal. If this module is used in a position controls, the TRIGGER value should be reduced (typical: 1...10).

#### 5.5.4 SIGNAL:U (Output polarity)

Command	Parameter	Unit	Group
SIGNAL:U X	x= +   -	-	EXP

This command is used to define the output polarity.

- + 0 % bis 100 %, normal output
- 100 % bis 0 %, changed output polarity

### 5.6 Output signal adaptation

#### 5.6.1 CURRENT (Rated solenoid current)

Command	Parameters	Unit	Group
CURRENT X	x= 500... 2600	mA	STD

The nominal output current is set. Dither and also MIN/MAX always refer to this current range.

#### 5.6.2 DFREQ (Dither frequency)

#### 5.6.3 DAMPL (Dither amplitude)

Command	Parameters	Unit	Group
DFREQ X	x= 60... 400	Hz	STD
DAMPL X	x= 0... 3000	0,01 %	

The dither<sup>4</sup> can be defined with this commands. Different amplitudes or frequencies may be required depending on the valve. The dither amplitude is defined in % (peak to peak value) of the nominal output current<sup>5</sup> (see: CURRENT command). The dither frequency is defined in Hz. Depending on the internal calculations, the frequency is adjustable in steps only<sup>6</sup>.



**CAUTION:** The PPWM and IPWM parameters influence the effect of the dither setting. These parameters should not be altered again after the dither has been optimized.

**CAUTION:** If the PWM frequency is less than 500 Hz, the dither amplitude DAMPL should be set to zero.

<sup>4</sup> The dither is a ripple signal which is superimposed on the current set point and is defined by the amplitude and frequency: the dither frequency and the PWM frequency. The dither frequency should not be confused with the PWM frequency. In some documentations the PWM frequency is described as a dither. This can be recognized by the lack of the dither amplitude.

<sup>5</sup> The dither amplitude is a command signal. Derivations between the commanded amplitude and the real amplitude are possible, depending on the dynamic of the solenoid.

<sup>6</sup> The lower the dither frequency, the smaller the steps. Therefore no practical problems are expected.

#### 5.6.4 PWM (PWM Frequency)

Command	Parameter	Unit	Group
PWM X	x= 61... 2604	Hz	EXP

The frequency can be changed in defined steps (61 Hz, 72 Hz, 85 Hz, 100 Hz, 120 Hz, 150 Hz, 200 Hz, 269 Hz, 372 Hz, 488 Hz, 624 Hz, 781 Hz, 976 Hz, 1201 Hz, 1420 Hz, 1562 Hz, 1736 Hz, 1953 Hz, 2232 Hz and 2604 Hz). The optimum frequency depends on the valve.



**Attention:** The PPWM and IPWM parameters should be adapted when using low PWM frequencies because of the longer dead times which forces a reduced stability of the closed loop control.

#### 5.6.5 ACC (Current loop auto adjustment)

Command	Parameter	Unit	Group
ACC X	x= ON OFF	–	EXP

Operation mode of the closed loop current control.

**ON:** In automatic mode PPWM and IPWM are calculated depending on the preset PWM-frequency.

**OFF:** Manual adjustment.

#### 5.6.6 PPWM (P gain of the current loop)

#### 5.6.7 IPWM (I gain of the current loop)

Command	Parameters	Unit	Group
PPWM X	x= 0... 30	–	EXP
IPWM X	x= 1... 100	–	

The PI current controller for the solenoids is parameterized with these commands.



**CAUTION:** These parameters should not be changed without adequate measurement facilities and experience.



**Attention,** if the parameter ACC is set to ON, these adjustments are done automatically.

If the PWM frequency is < 250 Hz, the dynamic of the current controller has to be decreased.

Typical values are: PPWM = 1... 3 and IPWM = 40... 80.

If the PWM frequency is > 1000 Hz, the default values of PPWM = 7 and IPWM = 40 should be chosen.

## 5.7 Special commands

### 5.7.1 TS (Sample time)

Command	Parameters	Unit	Group
TS            x	x= 5... 30	0,1 ms	<b>TERMINAL</b>

The control dynamics can be influenced with the sample time. Changes should only be made by persons who have sufficient knowledge of the dynamic system behavior.



**CAUTION!** After changing this value all time-dependent parameters must be checked and reset if necessary.

### 5.7.2 AINMODE (Scaling mode)

Command	Parameter	Unit	Group
AINMODE    x	x= EASY MATH	–	<b>TERMINAL</b>

This command is used to switch over the kind of input scaling.

The AINMODE is used to define the kind of parameterizing of the analogue inputs. The EASY mode (DEFAULT) supports a simple and application oriented input scaling.

The MATH mode supports the free input scaling by a linear equation. This mode is compatible to our older modules.



**Attention:** This command can be executed in the terminal window only. In case of switching back, DEFAULT data should be reloaded.

### 5.7.3 AIN (Analogue input scaling)

Command	Parameters	Unit	Group
AIN:I	i= W X		MATH
A	a= -10000... 10000	-	
B	b= -10000... 10000	-	
C	c= -10000... 10000	0,01 %	
X	x= V C	-	

This command offers an individual scalable input. The following linear equation is used for the scaling.

$$Output = \frac{a}{b}(Input - c)$$

The “**C**” value is the offset (e.g. to compensate the 4 mA in case of a 4... 20 mA input signal).

The variables **A** and **B** are defining the gain factor with which the signal range is scaled up to 100 % (e.g. 1.25 if using 4... 20mA input signal, defined in default current settings by A = 1250 and B = 1000). The internal shunt for the current measuring is activated with switching the **X** value.

The gain factor is calculated by setting the usable range (**A**) in relation to the real used range (**B**) of the input signal. Usable are 0... 20mA, means (**A**) has the value **20**. Really used are 4... 20mA, means (**B**) has a value of **16** (20-4). Not used are 0... 4mA. In a range of 20mA this is an offset of 20%, means a value of **2000** for (**C**). Last but not least (**X**) has to be set to **C** choosing current signal.

In this case AIN command would look like this:

AIN:I 20 16 2000 C or AIN:I 1250 1000 2000 C (see below)

#### Typical settings:

Command	Input	Description
AIN:X 1000 1000 0 V	0... 10 V	Range: 0... 100 %
AIN:X 10 8 1000 V OR AIN:X 1250 1000 1000 V	1... 9 V	Range: 0... 100 %; 1 V = 1000 used for the offset and gained by 10 / 8 (10 V divided by 8 V (9 V -1 V))
AIN:X 10 4 500 V OR AIN:X 2500 1000 500 V OR	0,5... 4,5 V	Range: 0... 100 %; 0,5 V = 500 used for the offset and gained by 10 / 4 (10 V divided by 4 V (4,5 V -0,5 V))
AIN:X 20 16 2000 C OR AIN:X 2000 1600 2000 C OR AIN:X 1250 1000 2000 C	4... 20mA	Range: 0... 100 %  The offset will be compensated on 20 % (4 mA) and the signal (16 mA = 20 mA – 4 mA) will be gained to 100 % (20 mA).  Each of this parameterization for 4... 20 mA is setting the range to 0... 100 %.

## 5.8 PROCESS DATA (Monitoring)

Command	Description	Unit
<b>WA</b>	Input signal	mm
<b>W</b>	Command value	mm
<b>X</b>	Feedback value	mm
<b>E</b>	Control error	mm
<b>U</b>	Output	%
<b>IA</b>	Solenoid current <sup>7</sup>	mA

The process data are the variables which can be observed continuously on the monitor or on the oscilloscope.

---

<sup>7</sup> The display of the solenoid current (in WPC-300 program) is damped in order to be able to bring out a stable signal.

## 6 Appendix

### 6.1 Failure monitoring

Following possible error sources are monitored continuously when SENS = ON/AUTO:

Source	Fault	Characteristic
Command signal PIN 9/10 4... 20 mA	Out of range or broken wire	The output will be switched off.
Feedback signal PIN 14 4... 20 mA	Out of range or broken wire	The output will be switched off.
Solenoids on PIN 3-4	Wrong cabling, broken wire	The power stage will be deactivated.
EEPROM (when switching on)	Data error	The output is deactivated. The module can only be activated by saving the parameters again!



**CAUTION:** Take care of the EOUT command. Changes will influence the behavior.

### 6.2 Troubleshooting

It is assumed that the device is in an operable state and there is communication between the module and the WPC-300. Furthermore, the valve control parameterization has been set with the assistance of the valve data sheets.

The RC in monitor mode can be used to analyze faults.



**CAUTION:** All safety aspects must be thoroughly checked when working with the RC (Remote Control) mode. In this mode the module is controlled directly and the machine control cannot influence the module.

FAULT	CAUSE / SOLUTION
ENABLE is active, the module does not respond, and the READY LED is off.	There is presumably no power supply or no ENABLE signal (PIN 15) present. Other faults are signalized with a flashing READY LED.
ENABLE is active, the READY LED is flashing.	<p>The flashing READY LED signals that a fault is detected by the module. The fault could be:</p> <ul style="list-style-type: none"><li>• A cable breakdown or no signal at the inputs (PIN 9 or PIN 14) if 4... 20 mA signals are parameterized.</li><li>• A cable breakdown or incorrect cabling to the solenoids (in the P version only).</li><li>• Internal data error: press the SAVE button to delete the data error. The system reloads the DEFAULT data.</li></ul> <p>With the WPC-300 operating program the fault can be localized directly via the monitor.</p>

FAULT	CAUSE / SOLUTION
<p>ENABLE is active; the READY LED is active; no current to the solenoid (no pressure-build-up).</p>	<p>To locate errors in the pressure-control-circuit, it is useful to start with the open loop pressure control (PIN 6 is not activated). In this case the module works like a power amplifier.</p> <ul style="list-style-type: none"> <li>• No pressure command input is available or the parameterization is incorrect. With the WPC-tool you can check if a command input is available. If not, you should check the wiring and/or the command set-point (in the PLC for example).</li> <li>• If the command input is correct, you have to check the valve control parameter. If the current is set too low (parameter CURRENT), the output current and the expected pressure are too low.</li> <li>• Wrong configured pressure sensor (if PIN 6 is active). If the input-scaling is set to voltage (V) and the pressure sensor supplies a current signal (4... 20mA), the measured pressure value is always high. The output signal to the valve is therefore low. For further checking: disable PIN 6.</li> <li>• The pressure valve is controlled correctly (the output is going up to the nominal current). In this case you may have a hydraulic problem or you are using free-wheeling-diodes in the solenoid plug. Please remove the free-wheeling-diodes to allow a correct current measurement.</li> </ul>
<p>ENABLE is active, the READY LED is active and the pressure is instable.</p>	<p>In many cases you may have a hydraulic problem.</p> <p>Electrical problems may be:</p> <ul style="list-style-type: none"> <li>• Electrical noise at the wire of the power supply.</li> <li>• Very long solenoid wiring (&gt; 40 m), disturbance in the current control loop<sup>8</sup>.</li> <li>• Instable current control loop. The adjustments of the PWM-frequency and the dither (frequency and amplitude) have to be checked carefully. Good experiences are made with: <ul style="list-style-type: none"> <li>a. PWM-frequency = 2600 Hz (higher frequency), the dither has to be aligned to the valve (amplitude and frequency).</li> <li>b. PWM-frequency = 100... 400 Hz (lower frequency), the dither amplitude is set to 0 % (disabled)<sup>9</sup>.</li> </ul> </li> </ul>
<p>ENABLE and START (PIN 6) are active, READY LED is ON, the pressure control works, but the pressure is not equal to the command input.</p>	<p>The system works generally, but wrong control loop settings or wrong adjustment of the input signals cause control errors.</p> <ol style="list-style-type: none"> <li>1. The feedback pressure is proportional to the command input pressure, but the values are too high or too low. <ol style="list-style-type: none"> <li>a. The scaling of the pressure valve is affected by the adjustment of the output current and the parameter <b>MAX</b>. The valve has a nominal range of 320 bar and the working pressure range is 240 bar, the parameter MAX has to be decreased. Procedure: Deactivate PIN 6, set the command input to 100 % and adjust the correct pressure by reducing the <b>MAX</b> parameter.</li> <li>b. AIN-command for sensor scaling. The working range of the sensor is 400 bar and the control range should be 240 bar. Following changes are to be done: <b>AIN:X 400 240 0 V.</b> For a sensor with current output you have to consider the 4... 20 mA scaling: <b>AIN:X 1250 1000 2000 C</b> 4... 20 mA plus sensor scaling: <b>AIN:X 1250 600 2000 C</b> (600 = 1000 * 240 bar / 400 bar).</li> </ol> </li> </ol> <p>Alternatively the input can now be done via a simplified parameterizing (see 5.3.5) which is default. With a terminal command (see 5.7.2) the mode of scaling can be switched over.</p>

<sup>8</sup> Maybe you have to adjust / optimize the solenoid control loop (P and I).

<sup>9</sup> In most applications (particularly pressure-actuated pumps) with pressure valves a lower PWM-frequency is the better solution.



FAULT	CAUSE / SOLUTION
<p>ENABLE and START (PIN 6) are active, the READY LED is active, the pressure control loop works, but the pressure is oscillating or the pressure UP and DOWN time is too slow.</p>	<p>The capability of the hydraulic system has to be checked. Deactivate PIN 6 for open loop control and check the pressure build up and down time. If the system is in open loop still instable, check the hydraulic and the dither/ PWM setup first.</p> <ol style="list-style-type: none"> <li>1. Check the parameters C:I, C:P and C:SC. The parameter C:SC has the following relevance: With this parameter you can increase or decrease the feed forward gain to the valve. C:SC 8000 (80 %) means, the remaining 20 % must be provided by the PID compensator. The integrator limitation should be set to 2500... 3500 (25 % ... 35 %) <sup>10</sup>.</li> <li>2. The C:P (P-gain) is to increase in steps <sup>11</sup> to the point where the pressure is going to be instable. At this point, C:P should be decreased for 30... 50 % to get an effectual stability margin.</li> <li>3. The integrator time constant C:I fixes the static error. Typical values are: 100 ms to 1200 ms. Optimize this parameter by monitoring the transient response.</li> </ol>
<p>ENABLE and START (PIN6) are active, the READY LED is active, and the pressure control loop works, but there are high errors mainly at lower or higher command pressure.</p>	<p>The non linearity of the valve is higher than the controlling range of the integrator. The parameter LIM:I should be increased.</p>
<p>ENABLE and START (PIN 6) are active, the READY LED is active, and the pressure control loop works. Lower pressure at the beginning causes that the system is not actuated and that no pressure build-up occurs.</p>	<p>In this case, the integrator threshold (activation point of the integrator) in combination with the controller setting is too high. The parameter LIM: S should be reduced.</p>

<sup>10</sup> The limit value should be higher than the remaining control range (100 % - C:SC), additionally you have to add a value to compensate the non linearity of the valve.

<sup>11</sup> Optimizing in steps is a general description. Our experience: you can change the parameters in steps from +20 % or rather -20 % for a rough adjustment of the actual value. For a fine adjustment you can select smaller steps.

### 6.3 Description of the command structure

The command structure:

[nnnn:i x] or  
[nnnn x]

Meaning:

**nnnn** - used for an arbitrary command name

**nnnn:** - used for an arbitrary command name, expandable by an index.

Indexed commands are indicated by the sign “:”

**i** oder **⌈** - is a dummy for the index. E. g. an index can be „A“ or „B“, depending on the direction.

**x** - parameter value, in case of special commands more than one parameter are possible.

#### Examples:

MIN:A 2000      nnnn = “MIN”, i = “A” and x = “2000”

OFFSET 50      nnnn = „OFFSET“ and x = „50“

C:IC 2000      nnnn = “C”, i = “IC” and x = “2000”

## 7 Notes